

Measuring Instructions

CompreFit® UNIVERSAL

1. Measure *length* from the **lateral** malleolus (**Outer Ankle Bone**) to **Bottom of Patella**.
Record in the corresponding **box G**.
2. Measure *circumferences* where indicated by the black dots; BK from the **lateral** malleolus (**Outer Ankle Bone**) - **A, B, C**; TC from the **lateral** aspect (**Top of Patella**) - **D, E, F**.
Record in the corresponding **lines (Right/Left)**.

CompreFit® Universal - TC (all measurements in cm)						
Measuring Point	Small	Medium	Large	X-Large	XX-Large	
F	23cm	48-58	56-66	64-74	74-84	n/a
E	15cm	43-53	51-61	58-68	69-79	
D	5cm	38-48	46-56	53-63	64-74	
∅ Point - Top of Patella						

CompreFit® Universal - BK						
Measuring Point	Small	Medium	Large	X-Large	XX-Large	
C	25cm	29-39	34-44	39-49	48-58	55-65
B	15cm	24-34	29-39	33-43	41-51	44-55
A	5cm	20-29	21-30	25-36	32-42	33-43
G	Note: If BK length (G) from A to C > 36cm order a size TALL					
∅ Point - Lateral Malleolus						

CompreBoot™ sizing chart and measuring instructions: p. 33 - 34